

** IMPORTANT INFORMATION **

 Brackets come pre-assembled ready for fitting. Dismantling the kit is not required for installation to your motorcycle.

The necessary Allen keys and fasteners have been provided.



The first step is to remove the original screen fitted to your bike.

Ensure any rubber well nuts have been retained.

We recommend wiping any dust or dirt that has built up underneath the screen with a clean cloth.



Loosely mount the bracket assemblies to the fairing using the new fasteners provided.



Pre-assemble screen fasteners and retain to screen with rubber washer on the inside of the screen – this makes it easier when fitting to brackets.

Loosely fit the screen to the brackets using the washers and locknuts.



Once everything is aligned, lightly tighten the bracket and screen fixings.

DO NOT OVERTIGHTEN. CRACKING MAY OCCUR.

** IMPORTANT INFORMATION **

• Do not attempt to make screen adjustments whilst riding.