

Moto Guzzi V85TT Screen Adapter Kit

Instructions

First job is to remove the bike's screen and place to one side in a safe place to avoid scratches and scrapes, etc.

Loosely mount the bracket assemblies onto the existing screen mount holes using the new M6 Countersunk screws and plastic finishing washers.



Before tightening, check the left and right hand brackets are parallel and are approximately 150mm apart.

Check that each bracket assembly is set in the same position before mounting the screen.

Keep the existing screen inserts in position and mount onto the brackets, using the new M6 Cap-Head bolts provided, loosely attach with the Nylock nuts and washers as shown.

Take care not to overtighten the Nylock nuts.



If you have opted for the Screen Baffle, than that can be attached as shown below by loosening the lower fasteners and slotting in position, making sure the square section of the coach bolts (if you have chosen the tool-less adjusters) are correctly seated in the baffle tabs.



If you have selected the Accessory Bar option, then that mounts onto the top slots as shown above, making sure the plastic washers are placed between the bar and the brackets.

The final step is to make sure all the parts are level, parallel and square to each other and secure before your test ride
Do not attempt to make adjustments whilst riding.

FINISH.