



# Fitting Instruction

Suzuki V-Strom 1050  
Screen Kit



**Palmer Products**

[www.palmerproducts.co.uk](http://www.palmerproducts.co.uk)

**\*\* IMPORTANT INFORMATION \*\***

- Brackets come pre-assembled ready for fitting. Dismantling the kit is not required for installation to your motorcycle.
- The necessary Allen keys and fasteners have been provided.
- If possible, installation will be easier with two people.

	<p>The first step is to remove the original screen fitted to your bike.</p> <p>Take note of the orientation of the 4 metal plates positioned front and back of the fairing.</p> <p>These plates and the square nuts are likely to drop onto the floor so be careful when removing.</p> <p>Ensure any fixings are retained as you will need these later.</p>
	<p>You will also need to remove the central screw from the toggle as shown. Ensure any fixings are retained as you will need these later.</p> <p>We recommend wiping any dust or dirt that has built up underneath the screen with a clean cloth.</p> <p>Remove the rubber insert from the original screen and fit this to same cutout on the Palmer Products Screen Kit.</p>
	<p>Remembering the orientation of the metal plates, start fitting the screen kit to the fairing.</p> <p>To fit the screen kit, you will need the fixing screws provided, the 4 metal plates, and 4 square nuts.</p> <p>We recommend doing the top fixings first (one at a time) before moving to the lower fixings.</p>
	<p>Once the four fixing screws are fitted, fit the central screw and spring to the toggle as shown.</p>



Pre-assemble screen fasteners and retain to screen with rubber washer on the inside of the screen - this makes it easier when fitting to brackets.



Loosely fit the washers and locknuts. Once everything is aligned, lightly tighten until rubber washers are compressed lightly.

**DO NOT OVERTIGHTEN. CRACKING MAY OCCUR.**

**\*\* IMPORTANT INFORMATION \*\***

- Do not attempt to adjust the screen whilst riding.