



# Fitting Instruction

## Windshield Kit



Palmer Products  
[www.palmerproducts.co.uk](http://www.palmerproducts.co.uk)

**\*\* IMPORTANT INFORMATION \*\***

- The following instructions are universal. Images and features may differ from your motorcycle. For any further assistance, please contact Palmer Products directly.
- Brackets come pre-assembled ready for fitting. Dismantling the kit is not required for installation to your motorcycle.
- The necessary Allen keys and fasteners have been provided.



The first step is to remove the original screen fitted to your bike.

Ensure any rubber well nuts have been retained.

We recommend wiping any dust or dirt that has built up underneath the screen with a clean cloth.



Loosely mount the bracket assemblies to the fairing using the new fasteners provided.

Check the brackets are parallel. This can be done by measuring the distance between the two brackets at top and bottom positions to see if they are the same.

Once parallel, tighten the fasteners until the brackets are secure.

**DO NOT OVERTIGHTEN**



If you have ordered the optional accessory bar, can be fitted as shown.

Note that the plastic washers need to be fitted on both ends of the accessory bar to prevent metal-to-metal contact.

Fully tighten fasteners to secure accessory bar to brackets.

**DO NOT OVERTIGHTEN**



Pre-assemble screen fasteners and retain to screen with rubber washer on the inside of the screen – this makes it easier when fitting to brackets.

Loosely fit the washers and locknuts. Once everything is aligned, lightly tighten until rubber washers are compressed lightly.

**DO NOT OVERTIGHTEN.**  
**CRACKING MAY OCCUR.**

**\*\* IMPORTANT INFORMATION \*\***

- Do not attempt to make screen adjustments whilst riding.